



Display Warmers
Models FW-CN-0066-C, 0100-C
Items 43120, 43121
Instruction Manual



Revised - 04/16/2018



Toll Free: 1-800-465-0234
Fax: 905-607-0234
Email: service@omcan.com
www.omcan.com




Table of Contents

Model FW-CN-0066-C / Model FW-CN-0100-C

Section	Page
General Information -----	3 - 4
Safety and Warranty -----	4 - 5
Technical Specifications -----	6
Installation -----	6
Operation -----	7
Maintenance -----	7 - 8
Parts Breakdown -----	8 - 11
Electrical Schematics -----	12 - 13
Notes -----	14
Warranty Registration -----	15



General Information

Omcan Manufacturing and Distributing Company Inc., Food Machinery of America, Inc. dba Omcan and Omcan Inc. are not responsible for any harm or injury caused due to any person's improper or negligent use of this equipment. The product shall only be operated by someone over the age of 18, of sound mind, and not under the influence of any drugs or alcohol, who has been trained in the correct operation of this machine, and is wearing authorized, proper safety clothing. Any modification to the machine voids any warranty, and may cause harm to individuals using the machine or in the vicinity of the machine while in operation.

CHECK PACKAGE UPON ARRIVAL

Upon receipt of an Omcan shipment please inspect for external damage. If no damage is evident on the external packaging, open carton to ensure all ordered items are within the box, and there is no concealed damage to the machine. If the package has suffered rough handling, bumps or damage (visible or concealed), please note it on the bill of lading before accepting the delivery and contact Omcan within 24 hours, so we may initiate a claim with the carrier. A detailed report on the extent of the damage caused to the machine must be filled out within three days, from the delivery date shown in the shipping documents. Omcan has no recourse for damaged products that were shipped collect or third party.

Before operating any equipment, always read and familiarize yourself with all operation and safety instructions.

Omcan would like to thank you for purchasing this machine. It's of the utmost importance to save these instructions for future reference. Also save the original box and packaging for shipping the equipment if servicing or returning of the machine is required.

Omcan Fabrication et distribution Compagnie Limitée et Food Machinery d'Amérique, dba Omcan et Omcan Inc. ne sont pas responsables de tout dommage ou blessure causé du fait que toute personne ait utilisé cet équipement de façon irrégulière. Le produit ne doit être exploité que par quelqu'un de plus de 18 ans, sain d'esprit, et pas sous l'influence d'une drogue ou d'alcool, qui a été formé pour utiliser cette machine correctement, et est vêtu de vêtements de sécurité appropriés. Toute modification de la machine annule toute garantie, et peut causer un préjudice à des personnes utilisant la machine ou des personnes à proximité de la machine pendant son fonctionnement.

VÉRIFIEZ LE COLIS DÈS RÉCEPTION

Dès réception d'une expédition d'Omcan veuillez inspecter pour dommages externes. Si aucun dommage n'est visible sur l'emballage externe, ouvrez le carton afin de s'assurer que tous les éléments commandés sont dans la boîte, et il n'y a aucun dommage dissimulé à la machine. Si le colis n'a subi aucune mauvaises manipulations, de bosses ou de dommages (visible ou cachée), notez-le sur le bon de livraison avant d'accepter la livraison et contactez Omcan dans les 24 heures qui suivent, pour que nous puissions engager une réclamation auprès du transporteur. Un rapport détaillé sur l'étendue des dommages causés à la machine doit être rempli dans un délai de trois jours, à compter de la date de livraison indiquée dans les documents d'expédition. Omcan n'a aucun droit de recours pour les produits endommagés qui ont été expédiés ou cueilli par un tiers transporteur.

General Information

Avant d'utiliser n'importe quel équipement, toujours lire et vous familiariser avec toutes les opérations et les consignes de sécurité.

Omcan voudrais vous remercier d'avoir choisi cette machine. Il est primordial de conserver ces instructions pour une référence ultérieure. Également conservez la boîte originale et l'emballage pour l'expédition de l'équipement si l'entretien ou le retour de la machine est nécessaire.

Omcan Empresa De Fabricacion Y Distribucion Inc. Y Maquinaria De Alimentos De America, Inc. dba Omcan y Omcan Inc. no son responsables de ningun daño o perjuicio causado por cualquier persona inadecuada o el uso descuidado de este equipo. El producto solo podra ser operado por una persona mayor de 18 años, en su sano juicio y no bajo alguna influencia de droga o alcohol, y que este ha sido entrenado en el correcto funcionamiento de esta máquina, y ésta usando ropa apropiada y autorizada. Cualquier modificación a la máquina anula la garantía y puede causar daños a las personas usando la máquina mientras esta en el funcionamiento.

REVISE EL PAQUETE A SU LLEGADA

Tras la recepcion de un envio Omcan favor inspeccionar daños externos. Si no hay daños evidentes en el empaque exterior, Habra el carton para asegurarse que todos los articulos solicitados estén dentro de la caja y no encuentre daños ocultos en la máquina. Si el paquete ha sufrido un manejo de poco cuidado, golpes o daños (visible o oculto) por favor anote en la factura antes de aceptar la entrega y contacte Omcan dentro de las 24 horas, de modo que podamos iniciar una reclamación con la compañía. Un informe detallado sobre los daños causados a la máquina debe ser llenado en el plazo de tres días, desde la fecha de entrega que se muestra en los documentos de envío. Omcan no tiene ningun recurso por productos dañados que se enviaron a recoger por terceros.

Antes de utilizar cualquier equipo, siempre lea y familiarizarse con todas las instrucciones de funcionamiento y seguridad.

Omcan le gustaría darle las gracias por la compra de esta máquina. Es de la mayor importancia para salvar estas instrucciones para futuras consultas. Además, guarda la caja original y el embalaje para el envío del equipo si servicio técnico o devolución de la máquina que se requiere.

Safety and Warranty

NOTICE

- To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.
- The device should never be left unattended during operation.
- Keep this manual in a safe location. When passing on/selling the device to a third party, the manual must be handed over along with the device.

Safety and Warranty

- The device is to be used indoors only.
- Any technical interventions, as well as assembly and maintenance are to be made by a qualified service technician only.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

1 YEAR PARTS AND LABOUR BENCH WARRANTY

Within the warranty period, contact Omcan Inc. at 1-800-465-0234 to schedule a drop off to either an Omcan authorized service depot in the area, or to an Omcan Service warehouse to repair the equipment.

Unauthorized maintenance will void the warranty. Warranty covers electrical and part failures, not improper use.

Please see www.omcan.com/warranty.html for complete info.

WARNING:

The packaging components (cardboard, polyethylene, and others) are classified as normal solid urban waste and can therefore be disposed of without difficulty.

In any case, for suitable recycling, we suggest disposing of the products separately (differentiated waste) according to the current norms.

DO NOT DISCARD ANY PACKAGING MATERIALS IN THE ENVIRONMENT!

Technical Specifications

Model	FW-CN-0066-C	FW-CN-0100-C
Temperature Range	30° - 85°C / 86° - 185°F	
Storage Volume	66 L / 2.33 cu. ft.	100 L / 3.53 cu. ft.
Rated Current	4.5 A	4.7 A
Rated Input Power	520 W	550 W
Grade of Waterproof	IPX4	
Electrical	115V / 60Hz / 1Ph	
Packaging Weight	44 lbs. / 20 kgs.	61.7 lbs. / 28 kgs.
Dimensions	17" x 22" x 20.3" 435 x 562 x 517mm	18.3" x 24.6" x 25.5" 467 x 625 x 650mm
Packaging Dimensions	19.7" x 24.6" x 22" 500 x 625 x 560mm	20.4" x 27" x 27.3" 520 x 690 x 695mm
Item Number	43120	43121

Installation

EXCLUSIVE POWER SOCKET

The power receptacle must have a reliable grounded connection.

DO NOT SHARE ON SOCKET

Never let the device share the common socket with any other appliance, otherwise the cable will become hot and fire might be resulted.

PROTECT CABLES

Never break or damage the cables otherwise current leakage and fire might be resulted.

DO NOT FLUSH WITH WATER

Never flush the device with water otherwise current leakage might be resulted.

KEEP AWAY FROM FLAMMABLES AND EXPLOSIVES

Never put any flammable or explosive materials inside the device such as ether, gasoline, alcohol, adhesive and explosives. Never place these dangerous products near the device.

INSTALLATION

- Place the device on top of an even and safe surface which supports the weight of the device and is not heat sensitive.
- At no time should you place the device on an inflammable surface (such as table cloth).
- You must not position the device near open fireplaces, electric ovens or any other heat sources.
- Position the device in such a way that the plug is easily accessible.

Operation

- Before first use, clean the inner sides and the shelves with a soft cloth and a mild cleaning agent. Afterwards, dry the device thoroughly.
- Remove the water bowl from the device, fill the water bowl with water and reattach the water bowl to the device.
- Connect the device to a single grounded power supply.
- Set the temperature as required for respective foods. You may adjust the desired temperature in the range between 30°C - 85°C.
- The temperature inside of the hot display can be read from the front display.
- Put the foods in appropriate containers before placing them inside the hot display and shut it by using the sliding door.
- Some of the device parts become very hot, always use safety gloves when placing or removing foods.
- Switch on the inner light when required using the light switch of the device.
- Disconnect the device from the power socket when the device is not in use.

Maintenance

- Before beginning with any cleaning or repairs make sure the device has been disconnected from the power socket and has cooled down completely.
- Don't use any acidic agents and make sure no water enters the device.
- To protect yourself from electric shock, never immerse the device, its cables or the plug in water or other liquids.
- Don't use any kind of pressure water jet for cleaning the device.

CLEANING

- The device should be cleaned regularly.
- Clean the device with a soft, damp cloth and a mild cleaning agent.
- Clean the shelves and the housing with a soft, damp cloth and a mild cleaning agent.
- Clean the water bowl regularly. Calcifications in the water bowl can be removed with common agents or liquids.
- Only use a soft cloth and make sure you never use any kind of abrasive agents or pads which could scratch the surface.
- After you have completed the cleaning procedure, you should use a soft and dry cloth to wipe dry and polish the surface.
- Make sure the device has been cleaned properly before storing it.

MAINTENANCE

- Check the plug from time to time to ensure it is not damaged in any way. Never use the device if the plug or cables are damaged. If damaged, they must be replaced by a qualified electrician.
- Only a qualified technician should carry out repairs and maintenance of the device. Do not attempt to repair the device by yourself.

Maintenance

REFERENCE

Item Number	Model Number	Description	Manufacturer Model Number
43120	FW-CN-0066-C	Display Warmer Showcase RTR-1D 115V/60HZ/1 QPS	RTR-1D
43121	FW-CN-0100-C	Display Warmer Showcase RTR-2D 115V/60HZ/1 QPS	RTR-2D


Parts Breakdown

Model FW-CN-0066-C 43120

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
60101	Decorating Gasket of Nut for RTR-1D	1	65439	Wire Supporter for RTR-1D	13	65448	Heating Tube for RTR-1D	25
60102	Nut Decorating Parts for RTR-1D	2	65440	Fixed Plate for Heating Panel for RTR-1D	14	60178	1/2GN Pan for RTR-1D	26
65431	Top Glass for RTR-1D	3	60498	Thermostat 125 Degree for RTR-1D	15	65449	Frame for RTR-1D	27
60103	Big Gasket of Nut for RTR-1D	4	60497	Thermostat 95 Degree for RTR-1D	16	65450	Aluminum Foil Heater for RTR-1D	28
65432	Rear Glass Support 2 for RTR-1D	5	65441	Baseboard for RTR-1D	17	60116	Cover of Cable Clip for RTR-1D	29
65433	Glass Mirror for RTR-1D	6	60211	Rubber Feet for RTR-1D	18	60117	Base of Cable Clip for RTR-1D	30
65434	Rear Glass Support 1 for RTR-1D	7	65442	Head Cover for RTR-1D	19	65451	Fixed Seat for Cable Clamp for RTR-1D	31
65435	Lower Bracket of Heating Tube for RTR-1D	8	65443	Top Light Cover for RTR-1D	20	60741	Power Line for RTR-1D	32
65436	Outside Pillar for RTR-1D	9	65444	Lamp Holder for RTR-1D	21	60215	Cable Clip for RTR-1D	33
65437	Inside Pillar for RTR-1D	10	65445	Tungsten Lamp for RTR-1D	22	60508	Switch for RTR-1D	34
65438	Side Glass for RTR-1D	11	65446	Reflector for RTR-1D	23	60202	Probe Pressing Plate for RTR-1D	35
60740	Plug-Type Fixer for RTR-1D	12	65447	Upper Bracket of Heating Tube for RTR-1D	24	60510	Controller for RTR-1D	36

Parts Breakdown

Model FW-CN-0066-C 43120




Parts Breakdown

Model FW-CN-0100-C 43121

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
60101	Decorating Gasket of Nut for RTR-2D	1	60498	Thermostat 125 Degree for RTR-2D	15	65465	Heating Tube Bracket for RTR-2D	29
60102	Nut Decorating Parts for RTR-2D	2	60497	Thermostat 95 Degree for RTR-2D	16	60735	Water Tray for RTR-2D	30
64883	Top Glass for RTR-2D	3	65458	Baseboard for RTR-2D	17	65466	Frame for RTR-2D	31
60103	Big Gasket of Nut for RTR-2D	4	60211	Rubber Feet for RTR-2D	18	60116	Cover of Cable Clip for RTR-2D	32
65452	Rear Glass Support 2 for RTR-2D	5	65459	Head Cover for RTR-2D	19	60117	Base of Cable Clip for RTR-2D	33
64878	Glass Mirror for RTR-2D	6	65460	Top Light Cover for RTR-2D	20	65451	Fixed Seat for Cable Clamp for RTR-2D	34
65453	Rear Glass Support 1 for RTR-2D	7	65444	Lamp Holder for RTR-2D	21	65450	Aluminum Foil Heater for RTR-2D	35
65435	Lower Bracket of Heating Tube for RTR-2D	8	65461	Tungsten Lamp for RTR-2D	22	60511	Power Line for RTR-2D	36
65454	Outside Pillar for RTR-2D	9	65462	Reflector for RTR-2D	23	60215	Cable Clip for RTR-2D	37
65455	Inside Pillar for RTR-2D	10	65447	Upper Bracket of Heating Tube for RTR-2D	24	60508	Switch for RTR-2D	38
65456	Side Glass for RTR-2D	11	65448	Heating Tube for RTR-2D	25	60202	Probe Pressing Plate for RTR-2D	39
60221	Plug-Type Fixer 17 for RTR-2D	12	60178	1/2GN Pan for RTR-2D	26	60510	Controller for RTR-2D	40
65457	Wire Supporter for RTR-2D	13	65463	Mid-Frame for RTR-2D	27			
65440	Fixed Plate for Heating Panel for RTR-2D	14	65464	Baseboard of Mid-Frame for RTR-2D	28			


Parts Breakdown

Model FW-CN-0100-C 43121




Electrical Schematics

Model FW-CN-0066-C 43120



Electrical Schematics

Model FW-CN-0100-C 43121



[illegible]



Warranty Registration

Thank you for purchasing an Omcan product. To register your warranty for this product, complete the information below, tear off the card at the perforation and then send to the address specified below. You can also register online by visiting:

Merci d'avoir acheté un produit Omcan. Pour enregistrer votre garantie pour ce produit, complétez les informations ci-dessous, détachez la carte au niveau de la perforation, puis l'envoyer à l'adresse spécifiée ci-dessous. Vous pouvez également vous inscrire en ligne en visitant:

Gracias por comprar un producto Omcan usted. Para registrar su garantía para este producto, complete la información a continuación, cortar la tarjeta en la perforación y luego enviarlo a la dirección indicada a continuación. También puede registrarse en línea en:

www.omcan.com/warrantyregistration.html

For mailing in Canada

Pour postale au Canada

Por correo en Canadá

OMCAN

PRODUCT WARRANTY REGISTRATION

3115 Pepper Mill Court,

Mississauga, Ontario

Canada, L5L 4X5

For mailing in the US

Pour diffusion aux États-Unis

Por correo en los EE.UU.

OMCAN

PRODUCT WARRANTY REGISTRATION

4450 Witmer Industrial Estates, Unit 4,

Niagara Falls, New York

USA, 14305

or email to: service@omcan.com



Purchaser's Information

Name: _____

Address: _____

City: _____ Province or State: _____ Postal or Zip: _____

Country: _____

Dealer from which Purchased: _____

Dealer City: _____ Dealer Province or State: _____

Invoice: _____

Company Name: _____

Telephone: _____

Email Address: _____

Type of Company:

☐ Restaurant ☐ Bakery ☐ Deli

☐ Butcher ☐ Supermarket ☐ Caterer

☐ Institution (specify): _____

☐ Other (specify): _____

Model Name: _____ Model Number: _____ Serial Number: _____

Machine Description: _____

Date of Purchase (MM/DD/YYYY): _____ Date of Installation (MM/DD/YYYY): _____

Would you like to extend the warranty? ☐ Yes ☐ No

Thank you for choosing Omcan | Merci d'avoir choisi Omcan | Gracias por elegir Omcan



Since 1951 Omcan has grown to become a leading distributor of equipment and supplies to the North American food service industry. Our success over these many years can be attributed to our commitment to strengthen and develop new and existing relationships with our valued customers and manufacturers. Today with partners in North America, Europe, Asia and South America, we continually work to improve and grow the company. We strive to offer customers exceptional value through our qualified local sales and service representatives who provide convenient access to over 3,500 globally sourced products.

Depuis 1951 Omcan a grandi pour devenir un des “leaders” de la distribution des équipements et matériel pour l’industrie des services alimentaires en Amérique du Nord. Notre succès au cours de ces nombreuses années peut être attribué à notre engagement à renforcer et à développer de nouvelles et existantes relations avec nos clients et les fabricants de valeur. Aujourd’hui avec des partenaires en Amérique du Nord, Europe, Asie et Amérique du Sud, nous travaillons continuellement à améliorer et développer l’entreprise. Nous nous efforçons d’offrir à nos clients une valeur exceptionnelle grâce à nos ventes locales qualifiées et des représentants de service qui offrent un accès facile à plus de 3500 produits provenant du monde entier.

Desde 1951 Omcan ha crecido hasta convertirse en un líder en la distribución de equipos y suministros de alimentos en América del Norte industria de servicios. Nuestro éxito en estos años se puede atribuir a nuestro compromiso de fortalecer y desarrollar nuevas relaciones existentes con nuestros valiosos clientes y fabricantes. Hoy con socios de América del Norte, Europa, Asia y América del Sur, que trabajan continuamente para mejorar y crecer la empresa. Nos esforzamos por ofrecer a nuestros clientes valor excepcional a través de nuestro local de ventas y representantes de los servicios que proporcionan un fácil acceso a más de 3,500 productos con origen a nivel mundial.

